



29. November 2018

## How to Perform a cold start

All You need to do is:

1. Switch of the power.
2. Dismount the Batteries. (J57 Plug on CELL 590 I/O Board)
3. Wait for 10-15 min.
4. Switch on the power.
5. Fill out the first coldstart picture.
6. And press F1, "then it will make a Restart.
7. Wait 1 min.
8. Now you can see which, Compressor type you have selected.
9. You can now fill out, all the setpoints. " Use Password = 1,5"
10. Mount the batteries again. (J57 Plug on CELL 590 I/O Board)

### Coldstart picture

```
01-01-94 17:25:35
: Screw compr. Control CELLmatic
COMP.TYPE: 1=GSV 2=GSF 0
COMP.SIZE: State size 0
REFRIGER.: State type 0
NODE NO. : State own number 0
CONTINUE : The above has to be completed
```

### The first picture

```
01-01-94 17:25:35
F6 CLA : P-Suction (C) 0.0 C
F5 SETUP. : Output (%) 0.0 %
F4 SET POINT: Ampere (%) 0.0 %
F3 MANUAL : T-oil compr (C) 0.0 C
F2 DISPLAY 2: P-discharge (B) 0.00 Bar
F1 STOP : GSV STOP
```

If You cannot see **GSV**, **GSF**, **GST** or **GSB**, you need make it all again. "you have not pressed F1"