



03 June 2009

Change the Working Hours at a CELLmatic 1502

Re. Working Hours

Stop the Compressor (Press on <F1>)

- Press on <RES> or <◀◀>
- Press on <ENT>
- Press on <F1> (Password)
- Press on <1> and <.> and <8> (1.8)
- Press on <ENT>
- Press on <REC> or <◀>
- Press on <REC> or <◀>
- Press on <REC> or <◀>
- Press on <F4> (Variables)
- Press on <F3> (Analog)
- Press on <F5> (By Number)
- Press on <4> and <2> and <6> (426)
- Press on <ENT>
- Press on <F4> (Selcet)
- Press on <F5> (New veardi)
- Set the new the value (XXXXX)
(The new value must be divided by 10)
- Press on <ENT>
- Press on <RES> or <◀◀>
- Press on <ENT>
- Press on <F1>
- Press on <0>
- Press on <ENT>
- Press on <RES> or <◀◀>
- Press on <F2>
- Press on <F2>
- Press on <F2>
- Press on <F2> (Check the Working hours)

Yours faithfully

Thy-tronic

Leif Jensby